



Angelcare®

AC1100 Video, Movement & Sound Monitor

Re-connecting Instructions:

1. Make sure the Parents Units and the Nursery Unit are turned off.
2. Turn the Nursery Unit on.
3. Press and release the left wing 4 times. The night light will start to flash.
4. Turn the Parents Unit on. A Blue screen will appear with the lost link icon on the top bar.
5. While pressing the talk back button on the right side of the Parents Unit, press and release the power key on the Parents Unit.
6. Video will appear on the Parents Unit's screen.




**For personal assistance contact our
Customer Care line: 011 791 6309
www.angelcare-monitor.co.za**

Angelcare®

AC1100 Video, Movement & Sound Monitor

Re-connecting Instructions:

1. Make sure the Parents Units and the Nursery Unit are turned off.
2. Turn the Nursery Unit on.
3. Press and release the left wing 4 times. The night light will start to flash.
4. Turn the Parents Unit on. A Blue screen will appear with the lost link icon on the top bar.
5. While pressing the talk back button on the right side of the Parents Unit, press and release the power key on the Parents Unit.
6. Video will appear on the Parents Unit's screen.



**For personal assistance contact our
Customer Care line: 011 791 6309
www.angelcare-monitor.co.za**